

User Manual & Technical Guide

Product Specifications

Feature	Description
Operation Modes	Auto / Manual / Off
Supported Devices	1 Fan + 1 Light
Speed Control	3-speed regulation for ceiling fans
Voltage	220V AC
Current Rating	2.5 μ A (microamps)
Technology	RF Wireless (Radio Frequency)
Signal Range	Long range; can penetrate walls
Sleep Timer	Yes, configurable from remote
Installation	DIY or by qualified electrician

Installation Instructions

 **Warning:** Ensure power is turned off before installation.

- 1. Disconnect Power:**
Turn off the circuit breaker or switch that supplies power to the fan and light.
 - 2. Connect Receiver Module:**
 - Fan & Light Input:** Connect the receiver's input wires to the main AC supply (L & N).
 - Fan Output:** Connect the fan wires from the receiver to the fan terminals.
 - Light Output:** Connect the light wires from the receiver to the lighting terminals.
 - 3. Secure the Module:**
 - Fit the receiver inside the fan canopy or ceiling rose.
 - Use provided mounting clips or zip ties if necessary.
 - 4. Reconnect Power:**
Turn on the mains power and test functionality using the remote.
-

Remote Control Overview

Button / Function	Description
Speed 1/2/3	Adjusts fan speed from low to high
Light ON/OFF	Turns connected light on or off
Fan ON/OFF	Turns the fan on or off
Timer (Sleep Mode)	Set auto shut-off after preset duration

 **Sleep Timer Options:** Varies by press combinations (see user sheet) — typically 1 to 4 hours.

Features & Benefits

-  **Three-Speed Fan Control:** Gentle breeze to powerful airflow.
-  **Remote Convenience:** Full control from anywhere in the room.
-  **Wall-Penetrating Signal:** Strong RF transmission, even across rooms.
-  **Universal Compatibility:** Works with most Indian ceiling fans and light fixtures.
-  **Energy Efficiency:** Auto shut-off via timer helps reduce electricity bills.
-  **Compact Design:** Easy to conceal, lightweight, and portable.

Testing & Troubleshooting

Issue	Solution
Remote not working	Replace battery / Ensure receiver is powered
Light works, fan doesn't	Check fan wiring / Try different speed settings
Weak signal / no response	Ensure within range (up to ~10–15m indoor)
Sleep timer not working	Reset remote / Refer to timer configuration section
RF interference	Avoid placing receiver near Wi-Fi routers or TVs

Customer Support

- **Warranty:** 6 months (manufacturer defect)
- **Support Contact:** Refer to Amazon product page or brand website
- **Returns:** 7-day replacement via Amazon